


WEISSWALL INSTALLATION GUIDE



WEISSWALL WIRING












WEISSWALL INSTALLATION GUIDE WIRING : 0-10 DRIVER WIRING




Max Distance at Full Load @ 2000 mA			Max Driver Load at 2000 mA		
18 AWG	16 AWG	12 AWG	Low (89ma)	Medium (149ma)	High (256 ma)
40 Feet	60 Feet	150 Feet	22 Feet	13 Feet	7 Feet



WEISSWALL MOUNTING











POWER FEED INSTALL TO OCTAGON BOX






NON POWER FEED INSTALL TO OCTAGON BOX








NON POWER FEED INSTALL - SHEET ROCK / SLAB CEILING










Feed AC Cable into Gripper


To adjust the length of cable depress the plunger on top of the gripper.












Snap the strain relief onto the wire and insert the assembly into the canopy thru hole.



WEISSWALL FIXTURE JOINING




WEISSWALL INSTALLATION GUIDE FIXTURE JOINING




New York, NY 1.833.SCOUTLD www.ScoutLighting.com Info@ScoutLighting.com


If Power is being passed between fixture lengths :

Connect the supplied male / female connectors to each other









WEISSWALL INSTALLATION GUIDE FIXTURE JOINING

Remove screw that ships in fixture joiner male bracket


Ensure the alignment pins line up and fall into place when sliding the fixture together.





WEISSWALL INSTALLATION GUIDE

FIXTURE JOINING



New York, NY 1.833.SCOUTLD www.ScoutLighting.com Info@ScoutLighting.com

Screw through the female bracket of the fixture into the male bracket.

Tightening this bracket will pull the fixtures together.

